

Instructions Manual- Portable Cot


1



Floorboard

- Remove the play yard from the carry bag and unfasten floorboard. Set floorboard and carry bag aside.
- Retire el corral de la bolsa de traslado y desate la tabla del piso. Deje a un lado la tabla del piso y la bolsa de traslado.


2



Keep center lock raised

- Stand play yard on legs and separate legs by pulling out on opposite corners.
- Keep center lock raised or rails will not safely lock into place.
- Coloque el corral en posición vertical sobre las patas y sepárelas tirando hacia afuera de las esquinas opuestas. Mantenga la traba central hacia arriba; de lo contrario, las barandas no se trabarán en posición.


3



Keep center lock raised

- Pull up on the center of each top rail (underneath elbow bend) to lock into place. Do this for each of the four top rails. Check to make sure each rail has locked into position. Rail may be locked in any order.
- Tire hacia arriba del centro de cada baranda superior (debajo del ángulo del codo) para trabarlas en posición. Repita el procedimiento para cada una de las cuatro barandas superiores. Verifique que cada baranda esté trabada en posición. Las barandas pueden trabarse en cualquier orden.

4




Push down on center lock.

Lock wheels.


- Push down on center of floor until center locks are flat; you will hear a "click". Be sure wheel locks are on when play yard is in place.
- Presione el centro del piso hasta que las trabas centrales queden planas; se oír un "clic". Asegúrese de que las trabas de ruedas se encuentren colocadas cuando el corral esté instalado.

5




- Place floorboard in play yard. Place the center adhesive strip in slot at bottom of play yard and secure. Repeat on other side.
- NOTE: If center adhesive strip does not align with slot, turn floorboard around and try again.
- Coloque la tabla del piso en el corral. Coloque la correa central adhesiva en la ranura en la parte inferior del corral y fijela correctamente. Repita el procedimiento en el otro extremo.
- NOTA: Si la banda adhesiva central no se alinea con la ranura, dé vuelta la tabla de piso y pruebe nuevamente.

6



- Remove mobile, parent's assist tray and bassinet. Take out floorboard. Pull up on finger tab in center of floor.
- Retire el móvil, la bandeja de asistencia para padres y la cuna. Retire la tabla del piso. Tire hacia arriba de la lengüeta en el centro del piso.

7




- To unlock top rails, push in on indicator buttons on each side of rail. Pull up slightly then push down. Do this for each of the four top rails in any order.
- Para destrabar las barandas superiores, presione los botones indicadores a ambos lados de cada baranda. Tire hacia arriba suavemente luego presione hacia abajo. Repita este procedimiento para cada una de las cuatro barandas superiores, sin importar el orden.

8



9



- Continue to pull up on finger tab to raise the floor and pull in the legs.
- Continúe tirando hacia arriba de la lengüeta para levantar el piso y empuje las patas hacia dentro.
- Wrap floorboard around play yard and fasten strips. Place inside carry bag for easy transportation. NOTE: Bassinet, changing station, and parent tray can fit inside the carry bag.
- Envuelva la tabla del piso alrededor del corral y ajuste las correas. Colóquelo dentro de la bolsa de traslado, para llevarlo fácilmente.
- NOTA: La cuna, el cambiador y la bandeja para padres caben dentro de la bolsa de traslado.

WARNING:

Failure to follow these warnings and the instructions could result in serious injury or death.

- The play yard, including side rails, must be fully erected prior to use.

Make sure all four rails are locked into place before use.

WARNING:

• Infants can suffocate

- In gaps between a mattress too small or too thick and side of product sides
- On soft bedding
- **NEVER** add a mattress, pillow, comforter or padding. Use **ONLY** mattress/pad provided by manufacturer.
- Strings can cause strangulation! **DO NOT** place items with a string around a child's neck such as hood strings, pacifier cords, etc. **DO NOT** suspend strings over play yard or attach strings to toys.
- Discontinue use of the product when child is able to climb out or reaches the height of 35 in. (890 mm) or weighing more than 30 lbs. (14 kg).
- When child is able to pull to a standing position, remove bumper pads, large toys, and other objects that could serve as steps for climbing out.
- **DO NOT** place play yard near window where cords from blinds or drapes may strangle a child.
- To reduce the risk of SIDS, pediatricians recommend healthy infants be placed on their backs to sleep, unless otherwise advised by your physician.
- Always provide the supervision necessary for the continued safety of your child. When used for playing, never leave child unattended.

WARNING:

• NEVER LEAVE INFANT IN PRODUCT

WITH **SIDES DOWN**. Infant may roll into space between pad and loose meshside causing suffocation.

- Before each usage or assembly, inspect product for damaged hardware, loose joints, missing parts or sharp edges. **DO NOT** use product if any parts are missing or broken. Call or write manufacturer for replacement parts and instructional literature if needed.

DO NOT substitute parts.

- If refinishing, use a non-toxic finish specified for children's products.
- **DO NOT** use a water mattress with this product.
- **DO NOT** leave child in product with side lowered. Be sure side is in

raised and locked position whenever child is in product.

- **NEVER** use plastic shipping bags or other plastic films as mattress covers not sold and intended for that purpose. They can cause suffocation.
- **DO NOT** add padding or other objects inside the play yard that will permit your child to climb out.

WARNING:

Using the Parent Tray

- To avoid possible tipping, **DO NOT** place more than 3 lbs (1.36 kg) in the parent tray.
- Never allow child to play with or hang on the parent tray.
- Always keep objects out of reach of child. Remove parent tray when child is able to pull himself up in play yard.

Using the Changing Station

- **FALL HAZARD**- To prevent death or serious injury, always keep child within arms reach. Never leave child unattended.

Always use the restraint belt. Check frequently to make sure it is secure.

- The changing station must be fully assembled and installed, including top rails, snaps and bottom pad, before using.
- Use changing station with only one child at a time.
- The changing station is not to be used for sleeping. When used for changing child, never leave child unattended.
- Never place a child under the changing station.

DO NOT use the changing station if it is damaged or broken.

- **Strangulation Hazard:** **NEVER LEAVE** changing station in place when child is in the play yard. Child can lift changing station and get neck trapped between the changing station and play yard frame.

- Discontinue using the changing station when your child can push up on hands and knees, is able to pull himself up, or reaches manufacturer's recommended maximum weight of 15 lbs (6.8 kg) which ever comes first
- Avoid serious injury from falling or sliding out.

WARNING:

Using Restraint Belt

Always use the restraint belt. Check frequently to make sure it is secure.

- The changing station must be fully assembled and installed, including top rails, snaps and bottom pad, before using.
- Use changing station with only one child at a time.
- The changing station is not to be used for sleeping. When used for changing child, never leave child unattended.
- **Never** place a child under the changing station.

For further inquiry or support, please contact:

ALLBABY LIMITED

5 Carol Lee Place, Off Quail Drive

Albany

North Shore City

Phone: 09 4473666

Email: sales@allbaby.co.nz

<http://www.ALLBABY.co.nz>